

Changing batteries

Your Audiologist will indicate the correct battery size for you:
(*Audiologist - please tick)

Battery size 312 Battery size 13

WHEN THE BATTERY POWER IS LOW

- you will hear 2 beeps when the battery has only a few hours left
- 2 beeps may be repeated in moderate intervals
- indicates it is time to change the battery

IF THE BATTERY RUNS OUT

- 4 beeps indicate the hearing aid is no longer operating
- the hearing aid turns off
- this is NOT an indication of malfunction

A worn out battery should be removed immediately and disposed of.

TO CHANGE THE BATTERY

Open the battery door completely by pushing the raised edge on the bottom of the instrument.

Remove the sticky label from the + side of the new battery.

Ensure that the positive (+) marking faces the positive (+) sign printed on the battery door.
Close the battery door.

Any moisture on the battery surface should be wiped off before use.

Please allow a few seconds for the battery to work to full capacity.

